


Jameson®

INSTRUCTION MANUAL

USB/TF/MP5/RADIO PLAYER

JS-9930BT



1. Power on / off
2. Mode/Ring off
3. Radio search backward/previous song
4. Search and scan the radio/ Long press
- 5.MENU
- 6.CH+/Pause in USB/SD mode
- 7.BAND/AMS/AV/answer the phone
- 8.EQ
- 9.Radio search forward/Next song
10. Loud
- 11.MUTE
12. CH- / choose last folder
- 13.Volume button/ Sound effect change
- 14.Remote Control receive window
- 15.MIC
- 16.TF Slot
- 17.USB Slot
- 18.AUX in
- 19.Reset
- 20.HD TFT Screen

1.Basic function

1..POW/MOD: Short press this button to power on , After power on. Short press to change the mode. In the Bluetooth mode. Short press to hang up. And long press to power off the unit.
2.BAND: In radio mode, short press this button to change the band: FM1-FM2-FM3. Long press to search and save the radio station automatically.

In USB/SD mode. Short press this button to change the playing format, as follows: MP3 Audio/JPG/MP5 Video.

In Bluetooth mode. Short press this button to show the latest phone call number. And you can make a call by the remote control (0--9 number). And press again you can dial.

3.

In the radio mode, short press this button to search the radio. Long press this button (about three second) to search the radio by manual.

In the MP3 mode. short press to read the next song or previous song. Long press to fast forward or back forward the current song.

4.MENU: Short press to go into the main menu

(1)You can choose the radio/USB/SD/ AUX format .

(2)In the setting mode.

* The system default volume setting:

* The system default CLOCK setting:

* Language setting: Chinese/English

5.Volume button/ SEL

Turn this button to control the volume. Short press repeatedly to change the sound effect as follows:

BASS---TREBLE---BAL---FAD---EQ OFF/ON---LOUD OFF/ON. When you choose the mode you need , you can turn left or right Volume Knob to select.

6.CH+: In the radio mode . Short press to choose the radio station forward . In the USB/SD mode. Short press is pause function.

7. CH-: In the radio mode . Short press to choose the radio station backward. In the USB/SD mode. When in video/ pictures. Short press to show the list of video/pictures. you can turn left or right Volume Knob to select.

8. Aux in slot .

9.SD/MMC slot(TF slot)

10. USB slot

11.Reset button

When the system is crash, you press this to restart.

2.Remote control Operations

1. Poweroff

2. Short press to go into dial status. Press (0-9) to show the phone number. short press again to make this phone call. Short press two time to call back the latest phone number.

3. In the dial status , short press to delete the number. In the call. Short press to hang up the phone.

4. Short press to change the mode.

5. In the radio mode. Short press to choose the station 1. Long press to save the current station to 1. In USB/SD/Bluetooth mode. Short press is pause/play function .

6. In the radio mode. Short press to choose the station 2. Long press to save the current station to 2. In USB/SD/Bluetooth mode. Short press is 10 seconds scan function.

7. In the radio mode. Short press to choose the station 3. Long press to save the current station to 3. In USB/SD/Bluetooth mode. Short press is repeat function.

8. In the radio mode. Short press to choose the station 4. Long press to save the current station to 4. In USB/SD/Bluetooth mode. Short press is random play function.

9. In the radio mode. Short press to choose the station 5. Long press to save the current station to 5. In USB/SD/Bluetooth mode. Short press is last 10 songs function

10. In the radio mode. Short press to choose the station 6. Long press to save the current station to 6. In USB/SD/Bluetooth mode. Short press is next 10 songs function.

11.After power on. Short press to choose LOUD OFF/ON.

12.In the radio mode. Short press to scan the station. And long press to scan and save the station automatically.

13. Short press repeatedly to change the sound effect as follows:BASS---TREBLE---BAL---FAD---EQ OFF/ON

14.Short press to control the volume. And you can choose the song with AMS button.


15. In the radio mode, short press this button to change the band: FM1-FM2-FM3. In USB/SD mode. Short press this button to change the playing format, as follows: MP3 Audio/JPG/MP5 Video.

16. In the radio mode, short press this button to search the radio. Long press this button (about three second) to search the radio by manual.

In the MP3 mode. short press to read the next song or previous song. Long press to fast forward or back forward the current song.

17.Short press is Mute function. In dial status. Short press is #

18.Short press to show the time . Long press to adjust the time. In dial status. Short press is *



3.Technical Parameters

Tuner Part:

Frequency Range-----87.5MHz-108MHz

noise-limited sensitivity-----FM≤15dB

signal to noise ratio (S/N)-----≥50dB

Usb/MMC/SD Part:

Frequency Response-----100Hz-10kHz(+10dB)

signal to noise ratio (S/N)-----≥45dB

Channel balance-----≤3 dB

Channel Separation -----≥35dB


Speaker impedance -----4Ω-8Ω

Real power output----->25W


Working voltage -----12V DC

Size dimension-----180mm(W)x52mm(H) vx115mm(L)

4. Installation Diagram



5. Wiring Diagram



6. Trouble shooting

Fault	Reasons	Solutions
LCD doesn't display	1. Yellow wire is not connected with battery + 2. Fuse of red wire is open	Assure yellow wire is connected with battery + Replace fuse
No sound	1. No power supply 2. Speaker wire is open circuit 3. SD/MMC card, U disk don't have song with corresponding format 4. SD/MMC card, U disk golden finger is dirt which causes bad contact.	Connect the power wire. Connect speaker wire. Check the contents of SD/MMC card, U disk Clean with absolute alcohol.
Low sound (not clear)	1. Power internal resistance is high. 2. Antenna is bad contact.	Replace the power supply Tighten the antenna plug.
Mono track	1. One channel of speaker wire is open circuit 2. Amplifier integrated circuit is damaged.	Connect speaker wire Replace the IC of amplifier


Note: Technical data is subject to change without prior notify.

Jameson®

KULLANIM KILAVUZU

USB/TF/MP5 / RADYO ÇALAR

JS-9930BT



- 1.Güç açık / kapalı
2. Mod / Zil sesi kapalı
3. Geriye doğru radyo araması / Önceki şarkı
4. Radyoyu ara ve tara/ Uzun basın
5. Menü
6. CH+ /USB/SD modunda duraklatma
7. BAND/AMS/AV/Telefona cevap verme
8. EQ
9. İleriye doğru radyo araması/ Sonraki şarkı
10. Yüksek ses
11. Sessiz
12. CH+ Son klasörü seç
- 13.Ses düğmesi/ Ses efekti değişikliği
14. Uzaktan kumanda alma penceresi
15. Mikrofon
16. TF yuvası
17. USB yuvası
18. AUX girişi
19. Sıfırlama
20. HD TFT Ekranı

Kullanım bilgileri

1. Pow/ mod : güç düğmesine basınız . açılım sonrası bu tuşa kısa süreli basım ile mod değişebilir. BT modunda iken kısa süreli basma gelen çağrıyı açacaktır . Uzun süreli basma ile de cihaz kapanacaktır

2.Band : radyo modunda iken , bu buton FM-1 /2/3 arasında değişim yapacaktır . uzun basınız ve radyo kanalı otomatik kaydedilecektir.

In usb / SD mode . Çalış formatında değişiklik yapacaktır . MP3 / jpg/ mp5 video oynatımı

BT modunda , kısa süreli basış 10 saniye süreli basınız .

arama seçenekleri için 10 saniye süreli basınız .

3.radyo modunda , kısa süreli basış ile radyo arama modunda olacaktır . 3 dakika gibi uzun süreli basışda manuel olarak başlatılacaktır .

MP3 modunda , kısa basarak bir sonraki ve önceki şarkılara geçiş yapabilirsiniz . Uzun süreli basışla ileri yada geri arama daha hızlı gerçekleşecektir.

4. MENU : Ana menuyu geçmek için basınız .

1- USB/ SD / AUX için seçim yapınız .

2- Ayarlar modunda

*Sistemin varsayılan ses seviyesi ayarı

*Sistemin varsayılan saat ayarı

*Dil ayarı: Çince/ İngilizce

5. Ses / Seçim

Bass / treble/ Bal / Fad / EQ açık – kapalı - Ses Açık – kapalı seçeneklerini

kullanabilirsiniz .

6. CH + : Radyo kanalı ileri arama USB/ Sd modunda iken tekrar bastığınızda durdurma

işlemi aktif olacaktır .

7.CH + : Radyo kanalı geri arama .

8. Aux In

9.SD/ MMC

10. USB giriş

11. Reset Butonu

Sistem zarar gördüğünde resetleyin .

2. Uzaktan Kumanda İşlevleri

1. Açma – kapama

2. 0-9 arasında görülen numaralar ile arama numarası çevrilir. İki kere üstüste bastığınızda , son

aranan numara menüsü ekrana gelecektir.

3. Arama menüsünde , kısa basış ile aranan numara silinir.

4. Mod değişimi kısa süreli basış ile gerçekleşir. .

5.Radyo modunda . istasyon seçilir . 1. Kaydetmek için uzun basınız .1. USB/SD / BT modunda , durdurma / çalma seçenekleri için kısa süreli basınız .

6. Radyo modunda . istasyon seçilir . 2. Kaydetmek için uzun basınız .2. USB/SD / BT modunda , tarama seçenekleri için 10 saniye süreli basınız .

7. Radyo modunda . istasyon seçilir . 3. Kaydetmek için uzun basınız .3. USB/SD / BT modunda , tekrar çalma seçenekleri için kısa süreli basınız .

8. Radyo modunda . istasyon seçilir . 4. Kaydetmek için uzun basınız .4. USB/SD / BT modunda , geçerli çalma fonksiyonu için kısa süreli basınız

9. Radyo modunda . istasyon seçilir . 5. Kaydetmek için uzun basınız .5. USB/SD / BT modunda , son 10 parça çalma fonksiyonu için kısa süreli basınız

10. Radyo modunda . istasyon seçilir . 6. Kaydetmek için uzun basınız .6. USB/SD / BT modunda , sonraki 10 parça çalma fonksiyonu için kısa süreli basınız

11. Cihaz açılır . Kısa süreli basma ile Ses açma - kapama seçilir.

12.Radyo modunda iken . İstasyon arama için basınız . Uzun süreli basarak kanal tarama ve kaydetme işlemi yapılır .

13. Ses efektini değiştirme için basınız . BASS- TREBLE – BAL - FAD - EQ açık – kapalı

14. Ses kontrolü sağlanır . AMS butonu ile şarkı seçimi sağlanır


15.Band değiştirme FM1/2/3 ve çalma dosya formatı

değiştirme seçenekleri MP3/ Mp5/ Jpeg/ Video

16.Radyo kanal arama

17. Sessiz Mod

18. Geçerli Zamanı gösterme .



Teknik Parametreler

Tuner Part:

Frequency Range-----87.5MHz-108MHz

noise-limited sensitivity-----FM≤15dB

signal to noise ratio (S/N)-----≥50dB

Usb/MMC/SD Part:

Frequency Response-----100Hz-10kHz(+10dB)

signal to noise ratio (S/N)-----≥45dB

Channel balance-----≤3 dB

Channel Separation -----≥35dB


Speaker impedance -----4Ω-8Ω

Real power output----->25W


Working voltage -----12V DC

Size dimension-----180mm(W)x52mm(H) vx115mm(L)

4. Kurulum eması



5. Kablolama diyagramı



7.Sorun giderici

hata	sebeeb	çözüm
LCD çalışmıyor	1. Sarı kabloyu kontrol ediniz 2. Kırmızı kablodaki sigorta açınız	Sigorta yenileyiniz . Sarı kabloyu kontrol ediniz .
Ses Yok	1. Güç kaynağı yok 2. Hoparlör kablosunda kısa devre 3. SD/MMC card da U disk de olan formatları desteklemiyor 4. SD/MMC card U diskteki dosya kirliliği kötü bağlantıya sebep oluyor .	Güç kablosunu bağlayınız . Hoparlör kablosunu bağlayınız . SD/MMC kart ı kontrol ediniz . Alkol ile temizleyiniz .
Ses Düşük	Güç iç bağlantı yüksek olabilir. Anten bağlantısı başarısız olabilir.	Güç kaynağını yeniden yapılandırın . Anten girişini gevşetin .
Tek Hoparlör	Hoparlör kanalında kısa devre olabilir. Amfi bağlantısı zarar görmüş olabilir.	Hoparlör kablosunu yeniden bağlayın . Amfi deki IC yi yenileyin

Not: Teknik veriler önceden bildirmeksizin değiştirilebilir.

MADE IN CHINA