

Jameson

Portable Speaker BT-1265

User Manual



To ensure correct operation and avoid damage, please read this user manual carefully before using this product.

Features

- 2.0CH portable Bluetooth speaker
- TWS function, achieve true wireless playing with double enhanced stereo sound
- Optimized voice assistant control
- Hands-free Mic for easy picking up the call
- Three different modes of RGB Lighting
- With A2DP Bluetooth, wireless stream music from any Bluetooth-enabled device
- USB support
- FM radio
- Line-in function, suitable for PC, MID, TV and other audio devices
- Built-in lithium rechargeable battery 1500mAh

Specifications

Bluetooth version: V5.1

Speaker Size: 2 inch*2

RMS power output: 8W, 4Ω

Peak power output: 16W, 4Ω

Battery Capacity: 3.7V, 1500mAh

Play time: 3 hours at maximum volume & 7 hours at 50% volume

Frequency Response: 80HZ-20KHZ


Bluetooth connecting range: 10m

Product size: 255(L)*87(W)*110(H)MM

Package Contents

- 1x Portable Bluetooth Speaker
- 1x Type-C Charging cable
- 1x Audio cable
- 1x User manual

Product Details



- ① Type-C Charging Jack
- ② AUX Port
- ③ USB Port
- ④ Backward/Volume Down
- ⑤ Forward/Volume Up
- ⑥ Mode/TWS Button
- ⑦ Mic Hole
- ⑧ Play/Pause & Voice Assistant Button
- ⑨ RGB Light
- ⑩ Power Button

Power On/Off

Long-press the Power button to turn the speaker on and off.

Bluetooth

- Turn the power button to “ON”. The speaker enter Bluetooth mode automatically.
- Activate *Bluetooth* of mobile phone and search for device name “JAMESON BT-1265” then connect it.
- Play the music from your mobile phone and enjoy.
- Long-press Forward or Backward button to select songs.
- Short-press Forward or Backward button to adjust volume up and down.
- Short-press Play/Pause button to play/pause the music.
- Long-press the RGB Light button to disconnect the Bluetooth connection with the mobile device.

TWS Function

- Turn on two identical speakers you want to pair, both under BT mode. Only need to set one of the two units.
- Long-press the TWS button to pair, speaker will make a tone to start to pair, and make a tone again after paired successfully.
- Make Bluetooth connection with your mobile phone to play music by the two paired Speakers.
- Long-press the TWS button again to exit TWS function.

Playing music from USB disk

- Turn the Power button to “ON”.
- Insert USB flash disk into slot, the speaker will play the stored music automatically.
- Long-press Forward or Backward button to select songs you like, short-press to adjust the volume up and down.
- Short-press Play/Pause to play or pause.

Notes: Under any playing mode, when you insert a USB disk to the speaker, it will switch to play the USB disk.

FM Radio

- Under FM radio state, the charging cable provided treat as antenna, please Insert the charging cable to the charging port before using.
- Turn the power button to “ON”, short-press the “MODE” button to enter radio state.
- Short-press “Play/Pause” button to mute the speaker. Long-press “Play/Pause” button to auto search the FM Channel and store it automatically.

- Long-press Forward or Backward button to change the stored FM channel, short-press to adjust the volume up and down.

AUX-IN

- For other compatible music devices, use an audio line cable to connect from the device's "Line Out" to the "Aux In" of this device, then enjoy...
- Under any playing mode, when you use the audio cable to connect the device, it will auto-switch to the AUX mode.
- When using an external device, all functions can be controlled by the external device.

RGB Light

The RGB light is on when speaker powered on, user can short-press the RGB Light button to turn the three different light modes and turn it off.

Activating Voice Assistant

- Make Bluetooth connection with your mobile phone.
- Long-press Voice Assistant button to activate voice assistant.

Hands-free call

- Under Bluetooth connection status, if there is an incoming call, user can short-press Play/Pause button to accept the call or long-press Play/Pause button to reject the call.
- During the call, user can long-press Play/Pause button to switch to talking on the phone.
- Short-press Play/Pause button or operate on mobile phone to end the call.

Reset Functionality

If the speaker does not turn off or respond, user can short-press the RESET button in Aux Port with a small round pin.

More Remarks

- Default volume is at 50% status of max volume.
- Play time may vary depending on volume level and music style.

How to charge

- The charger is not included in the package, please charge this speaker via a standard 5V/1~3A charger or via a PC.
- Charge time should be 3 hours. Once the speaker is full charged, the charging indicator will be off.
- The unit does not have power bank function, it is forbidden to charge other device via this unit or to connect other device via the USB port.
- To protect the battery, please do not use the speaker while it is charging.

Warning

- Please store and use this product in an environment of normal temperature.
- Please do not expose this product to rain or moisture environment.
- Please do not disassemble, repair or modify this product by yourself without authorization.
- When cleaning this product, please use a soft cloth or with little water if needed, please do not use chemicals for cleaning.
- In order to have an extended product life and protect your hearing, please avoid listening to songs on maximum volume for long time.
- The product is with built-in lithium battery, to avoid dangers, please do not discard or put it in the fire.